

Logitech® Harmony® 300



Broken remote? Confusing remote? Too many remotes?

Here's the replacement remote that's simple yet powerful. Press one button to watch TV. Enjoy quick and easy setup. And get unmatched device compatibility and control from America's best-selling brand of advanced remotes—now for simpler 4-component systems.

Replaces up to 4 remotes. Works with 5000+ brands.

- Supports more A/V devices than any other brand of remotes
- Controls what you own today and add tomorrow
- Online device database is updated daily—your remote will never become obsolete
- Simple online setup—download commands to your remote using your PC or Mac

FEATURE AT A GLANCE



Just one button to start watching TV

Turn on/off your TV and cable/satellite box with one button.



DVR/Blu-ray controls

Get the commands many remotes are missing, like List and Live.



Favorite Channel Buttons

Personalize your remote with one-button shortcuts to your favorite channels.



Intuitive Design

Buttons are grouped into logical zones, so you naturally go to the right command.

WORKS WITH

PC or Mac® setup

- Windows® XP, Windows Vista®, or Windows® 7
- Intel-based Mac OS® X 10.4.8 or later
- USB port
- Internet access

WHAT'S IN THE BOX?

- Harmony 300 Remote control
- USB cable
- 2 AA batteries
- User documentation
- 1-year limited hardware warranty



Which Harmony Remote is Right for You?

Find even more at logitech.com



Good

Better

Best

Control Features	HARMONY 300	HARMONY 650	HARMONY ONE
Devices supported	Up to 4	Up to 5	Up to 15
Display	No	Color screen	Color touch-screen
Activity-based controls	1 Activity	Multiple activities	Multiple activities
Layout optimized for DVD/TVo	X	X	X
Power Management			
Battery operated	X	X	
Rechargeable			With docking station
With Every Harmony Remote			
Contoured design to fit comfortably in your hand	X	X	X
Always growing database of entertainment devices	X	X	X
Live support	X	X	X
Help button assistance		X	X
1-year warranty	X	X	X
System Support			
Windows XP, Vista, 7	X	X	X
Intel-based Mac OS X (10.4.8 or later)	X	X	X